

Thanks for buying the  Wouxun KG-UV920P mobile radio.

This mobile radio offers latest design, enhanced features, solid performances and easy accessibility. We believe you will be pleased with the high quality and reliable features for all your communication needs.

Read this important information on the safe and efficient operation before using mobile radio. This manual is suitable for KG-UV920P.

Safety information

The KG-UV920P is an electrical apparatus, as well as a generator of RF(Radio Frequency) energy, and you should exercise all safety precautions as are appropriate of this type of device. These safety tips apply to any device installed in a well-designed amateur radio station.

- ⚠ Explosive atmospheres(gases, dust, fumes, etc.).Turn OFF your mobile radio while taking on fuel or while parked in gasoline service stations. Do not carry spare fuel containers in the trunk of your vehicle if your mobile radio is mounted in the trunk area.
- ⚠ Injury from radio frequency transmissions. Do not operate your mobile radio when somebody is either standing near to or touching the antenna, to avoid the possibility of radio frequency burns or related physical injury.
- ⚠ Dynamite blasting caps. Operating the mobile radio within 150m(500 feet) of dynamite blasting caps may cause them to explode. Turn OFF your mobile radio when in a area where blasting is in progress, or where "TURN OFF TWO-WAY RADIO" signs have been posted. If you are transporting blasting caps in your vehicle, make sure they are carried in a closed metal box with a padded interior. Do not transmit while the caps are being placed into or removed from the container.
- ⚠ Never allow unsupervised children to play in the vicinity of your mobile radio or antenna installation.
- ⚠ Be certain to wrap any wire or cable splices thoroughly with insulating electrical tape, to prevent short circuits.
- ⚠ Do not route cables or wires through door jambs or other locations where, through wear and tear, they may become frayed and shorted to ground or to each other.
- ⚠ Do not stand in front of a directional antenna while you are transmitting into that antenna. Do not install a directional antenna in any location where humans or pets may be walking in the main directional lobe of the antenna's radiation pattern.

Safety information

Wouxun

Twin Band FM Transceiver

- ⚠ In mobile installations, it is preferable to mount your antenna on top of the roof of the vehicle, if feasible, so as to utilize the car body as a counterpoise for the antenna and raise the radiation pattern as far away from passengers as possible.
- ⚠ During vehicular operation when stopped(in a parking lot, for example), make it a practice to switch to Low power if there are people walking nearby.
- ⚠ Never wear dual-earmuff headphones while driving a vehicle.
- ⚠ Do not attempt to drive your vehicle while making a telephone call on an autopatch using the DTMF microphone. Pull over to the side of the road, whether dialing manually or using the auto-dial feature.

Notice

- » All of the above advice is suited to the use of your **Wouxun** mobile radio and its accessories. If they do not function normally, please get in touch with the **Wouxun** dealer immediately.
- » If you use components or accessories not sold by Wouxun Company, Wouxun will not guarantee the safety and usability of the transceiver.

Checking the equipment	1
Standard accessories	1
Description of functions	2
Technical specifications	3
Pre-use installation	4-12
Transceiver installation	4
Connecting power source	6
Antenna connection	7
Front panel installation	8-11
Accessories installation	11-12
Getting started	13-16
Front panel	13
LCD	14
Back panel	15
Side panels	15
Hand microphone	16
Your first QSO	17-21
Adjusting the volume	18
Selecting frequency	18
Selecting output power	20
Transmitting	21
Shortcut operation chart	22
Menu operation sheet	23-26

Function description	27
Hotkey function guide	28-33
Menu operations	33-50
Step frequency settings (STEP) ----- Menu 1	33
Wide/Narrow bandwidth settings (W/N) ----- Menu 2	33
Two medium level power settings (MPOWSET) ----- Menu 3	33
Offset frequency settings (OFF-SET) ----- Menu 4	34
Transmission prompt settings (ROGER) ----- Menu 5	34
Beep prompt settings (BEEP) ----- Menu 6	34
Voice prompt settings (VOICE) ----- Menu 7	34
Busy channel lock-out (BCL) ----- Menu 8	35
Mute settings (SP-MUTE) ----- Menu 9	35
Scan mode settings (SC-REV) ----- Menu 10	36
Transmission time-out timer (TOT) ----- Menu 11	36
Transmission overtime alarm (TOA) ----- Menu 12	36
Caller ID transmission settings (ANI-SW) ----- Menu 13	37
Ring time (RING) ----- Menu 14	37
Editing Caller ID (ANI-EDIT) ----- Menu 15	37
DTMF sidetone settings (DTMFST) ----- Menu 16	38
Caller ID transmission mode (PTT-ID) ----- Menu 17	38
Transmission backlight (TX-LED) ----- Menu 18	38

Contents

Standby backlight (WT-LED) ----- Menu 19	39
Receiving backlight (RX-LED) ----- Menu 20	39
Deleting a channel (DEL-CH) ----- Menu 21	39
Editing a channel name (CH-NAME) ----- Menu 22	39
Priority channel switch (PRICH-SW) ----- Menu 23	40
Speaker settings (SPK- CONT) ----- Menu 24	40
Keypad autolock (AUTOLOCK) ----- Menu 25	41
Receiving CTCSS (RX-CTC) ----- Menu 26	41
Receiving DCS (RX-DCS)----- Menu 27	41
Transmitting CTCSS (TX-CTC) ----- Menu 28	41
Transmitting DCS (TX-DCS) ----- Menu 29	41
Repeater speaker switch (RPT-SPK) ----- Menu 30	42
Repeater PTT switch (RPT-PTT) ----- Menu 31	42
Repeater settings (RPT-SET) ----- Menu 32	43
Scan add (SCAN-ADD) ----- Menu 33	44
Automatic power-off (APO-TIME) ----- Menu 34	45
Single-tone pulse frequency (ALERT)----- Menu 35	45
Compand (COMPAND)----- Menu 36	46
Overheating detection (FAN-SET) ----- Menu 37	46
Voltage testing (LOW -V) ----- Menu 38	46
Voice scrambler (SCRAM) ----- Menu 39	47


Saving scanned CTCSS/DCS (SC-QT) ----- Menu 40	47
Noise reduction settings (ANS) ----- Menu 41	48
Scan group settings (SC-GROUP) ----- Menu 42	48
FM radio function (FM-RADIO) ----- Menu 43	48
Remote control (RC-SW) ----- Menu 44	49
Reset settings (RESET) ----- Menu 45	49
How to operate the FM radio	49-50
Turning on	49
Tuning radio stations	49
Storing and calling out FM radio stations	50
Exiting the FM radio mode	50
Repeater usage	51
Repeater PTT option	51
Repeater SPK option	51
Cross-band repeater entry and exiting	51
Hand microphone encoding function	52
Remote control function	52-60
Remote control activation	53
Stun	54
Kill	54
Monitoring	54

Contents


Inspection	54
Remote control power on / off	55
Remote changing settings	55-60
Wire-clone function	60
Optional accessories	61
Troubleshooting	62
Announcement	63

Checking the equipment

Carefully unpack the transceiver. We recommend that you identify the items in the following table before discarding the packing material.

If any item is missing or has been damaged during shipment, please notify your  dealer.

Standard Accessories



Description of functions

1. Frequency Range Suitable for any

Region of any Country:

(RX / TX) 136-174MHz & 400-470MHz
 136-174MHz & 400-480MHz
 136-174MHz & 216-280MHz
 136-174MHz & 420-520MHz
 144-146MHz & 430-440MHz
 144-148MHz & 222-225MHz
 144-148MHz & 420-450MHz

(RX) FM: 65MHz~108MHz (100K Frequency Spacing)

2. Band can be Set Freely

V/U U/V V/V U/U

3. Dual Reception

Twin Band Simultaneous Reception

4. Dual Display

Large LCD Dual Frequency Display,
 Two Completely Independent Operating Systems

5. Over 999 Memory Channels

Area Scanning Management Capability

6. Remote-head Mounting Capability

Multiple Installation Types, Convenient Usage

7. Full Duplex Cross-Band

Offset Frequency & Frequency Shift Direction
 Programmable
 UHF / VHF or VHF / UHF Cross-band Repeater Function

8. Both Stations can Form Combined Same Band or Different Band Repeat

9. High Output Power (VHF:50W / UHF:40W)

10. CTCSS / DCS Encode / Decode

11. Multiple Speaker Channel Settings

12. DTMF Hand Microphone

with Speaker, TX / RX Indicator and Volume Controller

13. Incoming Message Display

Caller ID display

14. DTMF Encoding and Decoding

15. Group Calls, All Calls and Selective Calls

16. 8 Group Scrambler

17. Priority Channel Scanning

18. APO Power Management

19. English Voice Guide

20. Minimum Operating Voltage Alarm

21. Stun and Kill Function

22. Single Tone Pulse Frequency

2100Hz / 1750Hz / 1450Hz / 1000Hz
 (Used when Activating Repeater Signal)

23. Selectable Three Color Backlight

24. Reduced Noise Settings

25. Remote Control Setting

26. Frequency / Channel Scanning with CTCSS / DCS Detection

27. Multiple Cooling Paths Fan

Technical specifications


General		Receiver	Wide bandwidth	Narrow bandwidth	
Frequency Range	Frequency Range Suitable for any Region of any Country: (RX / TX) 136-174MHz & 400-470MHz 136-174MHz & 400-480MHz 136-174MHz & 216-280MHz 136-174MHz & 420-520MHz 144-146MHz & 430-440MHz 144-148MHz & 222-225MHz 144-148MHz & 420-450MHz 66-88MHz & 136-174MHz 66-88MHz & 400-480MHz (RX) FM: 65MHz~108MHz (100K Frequency Spacing)	Adjacent Channel Selectivity	≤ 70dB	≤ 60dB	
		Intermodulation	≤ 65dB	≤ 60dB	
		Spurious Response	≤ 70dB	≤ 70dB	
Step Frequency	5KHz / 6.25KHz / 10KHz / 12.5KHz / 20KHz / 25KHz / 30KHz / 50KHz / 100KHz	Audio Response	+1~3dB(0.3~3KHz)	+1~3dB(0.3~2.55KHz)	
Memory Channels	999	Signal to Noise Ratio	≥ 45dB	≥ 40dB	
Work Mode	F2D / F3E	Audio Distortion	≤ 5%		
Operating Temperature	-20℃~+60℃	Audio Power	Transceiver ≤ 3W Hand Microphone ≤ 1W		
Antenna Impedance	50Ω	Audio distortion	Transceiver ≤ 3W Hand Microphone ≤ 1W		
Power Requirement	13.8VDC ± 15% (Negative Grounded)	Sensitivity	UHF/VHF:0.25μV		
Weight	1437.8g (including microphone)				
Dimensions	140 x 44 x 207 (mm)				
Transmitter	Wide bandwidth	Narrow bandwidth	Transmitter	Wide bandwidth	Narrow bandwidth
Type of Modulation	16K F3E	11K F3E	Max. Frequency Deviation	± 5KHz	± 2.5KHz
Adjacent Channel Power	≥ 70dB	≥ 60dB	Frequency Stability	± 2.5ppm	
Signal to Noise Ratio	≥ 40dB	≥ 36dB	Audio Distortion	≤ 5%	
Spurious	≥ 60dB	≥ 60dB	Output Power	50W/20W/10W/5W(VHF)	
Audio Response	+1~3dB(0.3~3KHz)	+1~3dB(0.3~2.55KHz)		40W/20W/10W/5W(UHF)	

Pre-use installation


Transceiver installation

Choose a safe place inside your vehicle, one which would to the greatest extent reduce possible harm to passengers inside the car while the car is moving. It is recommended to install the transceiver on the lower part of the front meter gauge, it will prevent the transceiver from colliding with the driver in the instance of emergency or sudden braking. Install the transceiver in an area with good ventilation and avoid installing in a place with direct contact with the sun.


1. Use the supplied self-tapping screws to install the support bracket to the vehicle.



2. Set the transceiver in the bracket, then insert the supplied combined screws and tighten, insure that the screws are fastened tightly. This will insure the support bracket and the transceiver do not get bumped lose when the vehicle hits bumps or shakes.




3. Use every screw slot along the side of the support bracket, you can set the transceiver to be installed at a different angle.



Connecting power source

The transceiver power source usage ranges from $13.8V \pm 15\%$. When your power source (or vehicle power source) reaches levels up to 16V, TX will be forbidden, however RX will operate as normal. When your power source (or vehicle power source) reaches levels as low as 11.5V, the transceiver will automatically shut off. So the transceiver does not exhaust the vehicles battery and affect the vehicles normal operation. (This feature is set by the Menu 38, see instruction on P46)



Special Reminder


» This transceiver's working voltage is $13.8V \pm 15\%$ DC.

■ Replacing the fuse

In the instance that the transceiver blows a fuse, first find out the reason, then solve the malfunction. If after installing the new fuse it once again blows a fuse, please sever the power source and immediately contact a local authorized **Wouxun** dealer or service center for assistance.

The specified fuse current is 15A, The specified power source current is 20A and above.


See the Fuse installation diagram on the right, after installation the fuse should be firmly secured to the copper set!



Antenna connection

Before operation, you must effectively install and adjust the antenna, installation success depends upon the type of antenna and whether or not the antenna is set up correctly. If you use the most suitable antenna and the antenna is installed correctly, the transceiver will attain the greatest results.

The transceiver antenna's impedance is 50 ohms, if the impedance is not at 50 ohms it will reduce the performance of the transceiver and possibly interfere with nearby broadcasting stations as well as other antenna's receivers, it could even harm the transceiver.




Front panel installation


The transceiver is supplied with two kinds of switchboard panels: Inclined switchboard panel and a flat switchboard panel.

■ Install inclined switchboard panel


(1) Lower alignment




(2) Cover alignment



(3) Close in the direction shown by the arrows




(4) Use the supplied screws to fasten




■ Install flat switchboard panel


(1) Lower alignment




(2) Cover alignment



(3) Close in the direction shown by arrows




(4) Use the supplied screws to fasten




■ Front panel and main station installation

(1) Connect the cable to the transceiver's 8 point socket.



(2) Proceed according to the arrow shown.



Front panel installation

Connection method for transceiver station to operating front panel:

The vehicle transceiver connection line uses 8 facets and 8 lead conducting wires (diagram 1),





Diagram 1

The two ends of the facets connect to the corresponding line: (Take note that direction of the connection lines on the left and right sides of the facet are not the same)



Left facet connection point 1
 Left facet connection point 2
 Left facet connection point 3
 Left facet connection point 4
 Left facet connection point 5
 Left facet connection point 6
 Left facet connection point 7
 Left facet connection point 8

Connect through the conducting wire to right facet 1
 Connect through the conducting wire to right facet 4
 Connect through the conducting wire to right facet 3
 Connect through the conducting wire to right facet 2
 Connect through the conducting wire to right facet 5
 Connect through the conducting wire to right facet 6
 Connect through the conducting wire to right facet 7
 Connect through the conducting wire to right facet 8

Therefore the conducting wires connection to the left facet is corresponding and the connection to the right facets 2 and 4 are swapped.



Special Reminder

» If the connection wires are not **Wouxun** Company supplied or dealer approved, **Wouxun** Company does not guarantee its safety and operational effectiveness!

■ Dismantling the front panel and transceiver

(1) Disconnect cover in the direction of the arrow


(2) Remove in the direction shown by the arrow



■ Installation of front panel support bracket

When the transceivers front panel is installed separately from the main platform, there is a supplied front panel support bracket designed especially for installation.


(1) First secure the support bracket with the supplied screws



Specification: 2.3X8 (4pcs)


Accessories installation

(2) First string the connection line through opening in the center of the support bracket, then close the bracket cover directly as shown by the arrows.




Outer speakers

The external speaker jacks can be connected to a 3.5mm single outlet. There are two speaker outlets located on the back of the transceiver.




Hand microphone installation

The transceiver comes supplied with two different types of hand microphone : Encoded hand microphone and unencoded hand microphone. Plug the connection cable into the 8 point socket located on the front panel.



Getting started

Front panel



- | | |
|--|---|
| 1 Master frequency set up hot key (See hot key operation 1)
/ Single-tone pulse key (see Menu 36) | 10 LCD |
| 2 Frequency or channel selection. (See hot key operation 2) | 11 Function keys / enters keys |
| 3 CTCSS / DCS encoding and decoding set up, CTCSS / DCS
scanning (see hot key operation 3) | 12 Exit / Cancel keys |
| 4 Save channel hot key (see hot key operation 4) | 13 Squelch level adjustment hot key (See hot key operations 9) |
| 5 Power output settings hot key | 14 Status indicator light
Orange standby indicator light
Green RX indicator light
Red TX indicator light |
| 6 VFO/MR switch over hot key (see hot key operation 6) | 15 Power switch button |
| 7 Frequency shift direction hot key (See hot key operation 7) | 16 Keyboard lock key (See keyboard lock) |
| 8 TDR Single and dual display switch hot key
(See hot key operation 8) | 17 Scanning key (See scanner function) |
| 9 Volume control (See volume control) | 18 Hand microphone outlet |

19 Channel knob